

Pens by Andrew

Information about the Larger size Ballpoint Pen



The pen nib is extracted and retracted by means of a twist mechanism. You hold the nib end and twist the body.

The mechanism is well greased by the manufacturer and can be a little stiff at first or if the pen has not been used for a while. It will loosen up with use.

You will eventually have to replace the parker style refill. You may also want to tighten up the mechanism onto the nib end if it has come loose.

It is very easy to service the mechanism or change a refill.

Firstly you take off the body. Simply pull the body away from the nib end



After sliding the body away from the nib end you can get at the mechanism. Unscrew the mechanism by gripping it at the top end (towards the nib) otherwise you'll just be winding the refill in and out.

With the mechanism apart you can replace the refill.

Don't lose the spring

When you put it back it only needs to be hand tight but make it as firm as possible.

Any queries just email me at andyandchris@talktalk.net